

TONER RESET FOR BROTHER MFC-L2750 PRINTERS

1. Open the front cover.
2. Press the "Return" and "Cancel" buttons at the same time. Hold both buttons for 1 to 2 seconds and then release.






Return Button


Cancel Button

3. Press the "Return" button again. You do not need to hold it down this time. Just press it once. The Reset Menu will appear.




Scroll Arrows


TNR-HC

TNR-HC Button

4. Use the "Scroll Arrows" on the touchscreen, to find "TNR-HC". Select by pressing the "TNR-HC" button once. This will take you to the Reset Page.
5. Press the "Yes" button on the touchscreen to confirm reset. The printer will display "Accepted"
6. Close the Front Cover to finish the reset process.
If you have any problems through the process, please call Ink Citi QLD on 0416 988 894